

ShockLog 248 Overview

ShockLog 248 Overview

The ShockLog[®] 248 is the entry model in the ShockLog product line of impact recorders, which includes the <u>ShockLog 298</u> impact recorder. Available in 10G, 30G, and 100G impact scale ranges, the ShockLog 248 monitors impact and internal temperature, provides peak value (time slot) and summary period journey profile data. ShockLog 248 delivers a visual alert that your product has encountered impact events that might affect its performance or safety, enabling immediate inspection and remediation at the time shipment is received or before installation in the field. The ShockLog 248 will record the detailed impact curve for the first and 14 most significant events. Up to 128 event notifications are maintained in the event summary log.

Features

- Record max peak X, Y, and Z and internal temperature
- Record impact events for up to 15 events
- Field-proven triaxial piezoelectric accelerometer technology
- Show direction of impact—X, Y, and Z
- User-definable alarm levels
- Programmable wake-up levels for maximizing battery life
- LED lights for visual notification of alarms and warnings
- Self-contained unit design, free of cables and wires
- iButton[®] and USB data transfer options
- IP67-rated, RF-screened
- Temperature/humidity sensor built into unit (optional)



The ShockLog 248 is a highly durable impact recorder that can be configured to monitor critical parameters, providing an unmistakable alert that an impact to a shipment or equipment may have compromised its integrity, performance, or safe operation.





ShockLog 248 Applications

The ShockLog 248 is designed for a variety of applications where a single range/ frequency filter is required. This versatile impact sensing solution also offers optional environmental recording capability, monitoring your products in transit, in use, and in storage.

Below is a small sampling of applications in which the ShockLog 248 has been used:

- Automotive parts: motor, pumps, windshields, engines, transmissions
- Transportation: rail cars, barges, cranes, trucking fleets
- Energy: oil and gas drilling, power transformers, nuclear materials, solar panels, wind turbines
- Defense and aviation: lasers, missiles, munitions, gyroscopes, aircraft engines, rocket boosters, satellites
- Medical and research: lab equipment, particle accelerator systems, MRI machines, dental chairs

ShockLog 248 Overview

Data Transfer

The ShockLog has two options for data transfer: USB or iButton® interface.

Gain complete programming control and full data access over the USB port. iButtons allow for easy control for setup, download, and start and stop of the ShockLog. An overview can be downloaded using an iButton while keeping the unit secure and tamperproof.

ShockLog Software Allows for Configuration, Data Extraction, and Analysis

- Simple Windows[®]-based software program
- Clear instructions for quick deployment and easy data analysis
- Overview of the entire journey with peak acceleration values for all three axes reported on a time basis
- Export data into programs such as Excel for more detailed analysis

Protect Your High Value Assets

Customers use the ShockLog 248 impact recorder to:

- Alert recipients and operators to inspect goods and equipment for potential damage
- Detect mishandling during shipping, operation or storage, enabling you to identify and assign accountability and take corrective action
- Make adjustments to product packaging, loading process, carriers, or mode of transport
- Help identify opportunities for improvement through journey profiling



*Always use lithium batteries for journeys where the temperature may be outside the -5°C to $+50^{\circ}$ C range.

^The capacity of alkaline batteries drops dramatically when exposed to temperatures below 10 $^{\circ}\mathrm{C}.$

*If using a lithium battery and the ShockLog will be travelling by air, make sure the battery is approved for air cargo.

*^If the batteries are accidentally installed with the wrong polarity, the ShockLog will not be damaged; however, the life of the battery may be severely affected.



Key Specifications

Operating Temperature Range:	-40°F to 185°F -40°C to 85°C
Scale Range (Factory Set):	10G, 30G, 100G
Cut-off Frequency Options (Factory Set):	40Hz, 90Hz, and 250Hz
Time Slots:	Up to 262,000
Time Slot Length:	10 seconds to 1 hour
Size:	3.3in x 3.3in x 2.2in 84mm x 84mm x 55mm
Weight:	1.1lbs (without battery) 455g (without battery)
Battery Type:	1 x 3.6V Lithium battery* 1 x 1.5V Alkaline AA battery^
Battery Life:	Up to 12 months w/ lithium battery

Humidity & Temperature Factory Fit Option

Humidity:	0-100% RH
Temperature:	-40°F to 185°F -40°C to 85°C
Dew Point:	-40°F to 185°F -40°C to 85°C 0-100% RH

